

Content of spare part packages

	MiR100/200	MiR250	MiR500/1000
Motor Controller	x		
Motor Relay			x
Motor Brake Relay	x		
Motorboard			x
Powerboard			x
DFI	x	x	x
NUC	x		
MiR Board	x		
Speaker	x		
Emergency stop module	x		
24 V supply	x		
Router	x	x	x
SICK Scanner	x	x	x
SICK Memory Plug	x		x
SICK MOC Module			x
Camera		x	x
Proximity sensor module		x	x
Safe stop relay		x	