




Bulletin HY30-8205-INST/EU

Installation and start-up information Hydraulic Motors Series F11/F12


Effective: August 25, 2011

Supersedes: January 18, 2011




VIKTIGT • IMPORTANT • IMPORTANTE • WICHTIG • TÄRKEÄTÄ

- SE** Rotationsriktning flödesriktning. Gäller både pump och motor.
- UK** Direction of rotation corresponding FLOW direction. Apply to both pump and motor.
- DE** Drehrichtung entsprechend der Durchflußrichtung. Paßt sowohl für Pumpe als auch Motor.
- FR** Sens de rotation – Sans de débit correspondant – Valable également pour les pompes et les moteurs.
- ES** El sentido de giro corresponde a la dirección del caudal. Esto es aplicable tanto en bombas como en motores.
- SF** Pyörimissuunta virtaussuunta. Koskee sekä pumpua että moottoria.
- IT** Senso di rotazione in funzione della direzione di mandata. Vale indifferentemente, sia come pompa, che come motore.





- SE** Använd våra rekommenderade ledningsdimensioner. Smala sugledningar och krökar kan orsaka kavitation, som medför oljud och skador.
- UK** Follow our recommendations regarding pipe dimensions. Narrow pipes and bends can cause cavitation, which will generate unnecessary noise and damage.
- DE** Beachten Sie unsere Empfehlungen bezüglich Rohrabmessungen. Dünne Rohre und starke Biegungen können Kavitationen hervorrufen, die unnötige Geräusche und Schäden verursachen.
- FR** Prière de suivre nos recommandations concernant les diamètres des tuyauteries. Des coudes et des tuyaux de diamètre trop réduit donnent lieu à du bruit et provoquent éventuellement une détérioration du matériel.
- ES** Siga nuestras recomendaciones respecto al tamaño de las tuberías. Tubos y codos estrechos pueden causar cavitación, lo cual dará lugar a averías y ruidos innecesarios.
- SF** Käytä suositteliamme kokoisia putkia. Ohuet imuputket ja putkikäyrät voivat aiheuttaa kavitaatiota, seurauksena melua ja vaurioita.
- IT** Seguire le nostre raccomandazioni circa il dimensionamento del diametro delle tubazioni. Diametri insufficienti e curve strette possono creare cavitazione e conseguentemente rumorosità superflua e ulteriori danni.



- SE** Garantien endast giltig om pump/motor ej är isärtagen.
- UK** The guarantee is only valid if the pump/motor has not been disassembled.
- DE** Die Garantie gilt nur, wenn Pumpe/Motor nicht zerlegt sind.
- FR** La garantie est valable uniquement moteur/pompe non démonté(e).
- ES** La garantía solo es válida si la bomba / el motor no ha sido desarmada/o.
- SF** Takuun voimassaolo päättyy, jos pumpppua/moottoria on purettu.
- IT** La garanzia è valida a condizione che pompa/motore non siano smontati.


- SE** Anslut dränerledningen till den högst belägna dräneranslutningen på pumpen/motorn. Anslut om möjligt dränerledning direkt till tank för att undvika högt tryck i huset.
- UK** Use the drain connection, which is positioned up-permost on the pump/motor.
- DE** Benutzen Sie den Leckölanschluß, der je nach Einbaulage der Maschine am höchsten liegt.
- FR** Utiliser l'orifice de drain sa trouvant le plus haut sur le moteur la pompe.
- ES** Utilice la conexión de drenaje más etta según la posición de la bombamotor.
- SF** Liitä vuotoputki pumpun/moottorin ylimpään vuotoliitäntään. Mikäli mahdollista, liitä vuotoliitäntä suoraan säiliöön, jotta koneen pesässä et syntyisi korkea painetta.
- IT** Usare sempre il drenaggio piu' alto conformemente al posizionamento della pompa.

F11**F12**

- SE** Använd olja och filter enligt våra rekommendationer.
- UK** Use oil and filter as recommended by us.
- DE** Gebrauchen Sie das von uns empfohlene Öl und den von uns vorgeschlagenen Filter.
- FR** Employer une huile et un filtre conformes à nos recommandations.
- ES** Utilice aceites y filtros de acuerdo con nuestras recomendaciones.
- SF** Käytä suosituksemme mukaista öljyä ja suodatinta.
- IT** Usare l'olio e i filtri da noi raccomandati.

- SE** Rengör hydraulsystemet noga innan olja påfylls.
- UK** Carefully clean the hydraulic system before the system is filled with oil.
- DE** Säubern Sie vor Einfüllung des Öls sorgfältig das System.
- FR** Nettoyer soigneusement le système avant de la remplir d'huile.
- ES** Limpie minuciosamente el sistema antes de llenarlo de aceite.
- SF** Puhdista hydraulijärjestelmä huolellisesti ennen öljyllä täyttämistä.
- IT** Si raccomanda la massima pulizia, specialmente nei raccocchi a nel cambio dell'olio.

- SE** Fyll huset med olja före start.
- UK** Fill the casing with oil before start up.
- DE** Füllen Sie vor Beginn das Gehäuse mit Öl.
- FR** Remplir la carter de la pompe ou du moteur avant la mise en route.
- ES** Llene la carcasa de aceite antes de ponerla en marcha.
- SF** Täytä pesä öljyllä ennen käynnistystä.
- IT** Prima della messa in funzione riempire d'olio la carcassa-pompa.



Position notification regarding Machinery Directive 2006/42/EG:

Products made by the Pump and Motor Division (PMD) of Parker Hannifin are excluded from the scope of the machinery directive following the "Cetop" Position Paper on the implementation of the Machinery Directive 2006/ 42/ EC in the Fluid Power Industry.

All PMD products are designed and manufactured considering the basic as well as the proven safety principles according to:

- SS EN ISO13849-2:2008-09, C.2 and C.3 and,
- SS EN 982+A1:2008,

so that the machines in which the products are incorporated meet the essential health and safety requirements.

Confirmations for components to be proven component, e. g. for validation of hydraulic systems, can only be provided after an analysis of the specific application, as the fact to be a proven component mainly depends on the specific application.

Dr. Hans Haas

General Manager Pump and Motor Division Europe
Chemnitz, Chomutov, Trollhättan, Kingswinford

**WARNING – USER RESPONSIBILITY**

FAILURE OR IMPROPER SELECTION OR IMPROPER USE OF THE PRODUCTS DESCRIBED HEREIN OR RELATED ITEMS CAN CAUSE DEATH, PERSONAL INJURY AND PROPERTY DAMAGE.

This document and other information from Parker-Hannifin Corporation, its subsidiaries and authorized distributors provide product or system options for further investigation by users having technical expertise.

The user, through its own analysis and testing, is solely responsible for making the final selection of the system and components and assuring that all performance, endurance, maintenance, safety and warning requirements of the application are met. The user must analyze all aspects of the application, follow applicable industry standards, and follow the information concerning the product in the current product catalog and in any other materials provided from Parker or its subsidiaries or authorized distributors.

To the extent that Parker or its subsidiaries or authorized distributors provide component or system options based upon data or specifications provided by the user, the user is responsible for determining that such data and specifications are suitable and sufficient for all applications and reasonably foreseeable uses of the components or systems.

Offer of Sale

Please contact your Parker representation for a detailed "Offer of Sale".



Parker Hannifin Manufacturing Sweden AB
Pump and Motor Division
SE-461 82 Trollhättan
Sweden
Tel. +46 (0)520 40 45 00
Fax +46 (0)520 371 05
www.parker.com/euro_pmd

HY30-8205-INST/EU
Art. No 3793839-03

© Copyright 2011
All rights reserved